



How to connect with Wiegand reader to C3


Wiegand reader could work with C3 through connecting Wiegand output to wiegand input of C3 controller, and the wiegand output signal should be Wiegand 26 and 34 formats.

How many Wiegand readers could C3 connect?

C3 can connect different number of Wiegand readers in different mode. C3-100 can connect two Wiegand readers in the one-door two-way mode. C3-200 provides four readers, which can be connected in the two-door two-way mode. C3-400 provides four readers, which can be connected in the two-door two-way or four-door one-way mode.

Connected with Wiegand readers

The Wiegand interfaces provided by the C3 series can be connected to different types of reader. Our C3 controller support Wiegand 26 and 34 formats RFID reader;




Connected with Wiegand readers



Cable Connection

All readers are color coded in the same way to correspond to the labeled inputs on the control unit. We need to connect WD0, WD1 and GND.



Connection between C3 and Readers

- Note:**
- 1.If your card reader does not use the voltage of DC 12V, an external power supply is needed.
 2. A reader should be installed at a height of about 1.4 meter above the ground and at a distance of 30-50mm away from a door frame.

